

HEXTIO



Your personal clean air companion.

Featuring technology inherited from Radic8's VIRUSKILLER™-enabled devices, Hextio is the perfect clean air unit for personal use, situated on a desk, counter, or bedside table.

Features

- **All-in-One:** Hextio combines air filtration, gas neutralization, and even a miniature VIRUSKILLER™ UV-C Reactor Chamber for all-in-one desktop clean air performance.
- **Directional Airflow:** Hextio's airflow hood can be directed towards an individual's breathing zone, providing clean, fresh air where it matters most.
- **Plug and Play:** Simple operation means out-of-the-box operation, with no complex installation or setup required.
- **Sleep Mode:** Hextio features an ultra-quiet sleep mode for overnight protection.

Technical Specifications		Power	15 W
Coverage	Personal	Installation	Freestanding
Net Weight	1.33 kg (2.93 lbs)	Accessories	220-240 V to 12V DC adaptor (included)
Box Weight	1.93 kg (4.25 lbs)	Warranty	1 Year
Dimensions (mm)	126 x 106 x 330	Unit Lifespan	10 Years
Dimensions (in)	4.96 x 4.17 x 13	Color	White or Black
Noise	40-49 dB	Power Options	220-240 V to 12V DC adaptor (included) 12V Power bank (optional)
Airflow	12-20 CFM	Plug Type	Universal adaptor plug, includes UK/USA/EU
UV-C Lamps	1 x 6W (253.7 nm)		
TiO ₂ Hexagonal Tubes	10		
Reactor Lifespan	8,000 Hours		
Composite carbon and HEPA Filter Lifespan	4,000 Hours		

Radic8's VIRUSKILLER™ range is not FDA-cleared / FDA-approved. EPA Est. Number: 98858-KOR-1. Radic8 is registered with the Electrical and Electronic Equipment Act, according to § 6 sect.(3). WEEE Registration number DE 51521894. Manufactured by INB Korea.

safe indoor air. everywhere.

Please contact us or visit www.EPSclean-air.com for more information.

EPS Clean-Air is a product segment under EPS Decontamination – A part of EPS Vascular. VIRUSKILLER is a trademark of Radic8. © EPS Vascular AB. All rights reserved. | +46 (0) 10 33 00 511 | info@epsclean-air.com

